



Figure 1

1. INTRODUCTION

AMP* Extraction Tool 91302-1 is designed to extract individual AMP CST-100 receptacle contacts from CST-100 connector housings. See Figure 1 for a typical CST-100 receptacle contact and connector housing. Read this sheet carefully before using the tool.

NOTE *Figures and illustrations are for identification only, and are not drawn to scale.*

2. DESCRIPTION

The tip of this extraction tool is designed to enter the locking lance slot on the connector and depress the contact locking lance. The tool stop is designed to prevent contact damage due to overinsertion of the extraction tool.

3. EXTRACTION PROCEDURE

1. With the extraction tool positioned as shown in Figure 1, insert the tip straight into the slot until the tool stop bottoms on the connector.
2. Grasp the wire attached to the contact being removed, and pull the contact out of the connector housing.

NOTE

Do not re-insert the used contact into the connector housing.

3. Remove the tool from the connector housing.

4. MAINTENANCE AND INSPECTION

To ensure proper operation, it is recommended that the tool be inspected immediately on its arrival and at regularly scheduled intervals. The tool is not repairable and should be replaced when worn or damaged. It is recommended that the tool be stored in a clean, dry place and cleaned with a soft, lint-free cloth.

Additional tools can be purchased from:

CUSTOMER SERVICE (038-35)
 AMP INCORPORATED
 P.O. BOX 3608
 HARRISBURG, PA 17105-3608

5. REVISION SUMMARY

Per EC 0990-1304-98:

- Initial release of instruction sheet